



Notching of inner sternpost for filling transoms

LWL

WL 5

Fashion Timber

Top of Frame Foot

Rabbit on Sternpost

Bearding Line

Inner Sternpost

Bottom of Frame Foot

32

31

30

29

28

27

26

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11